

INSTRUCTIONS

Keep these instructions - Gardez ces instructions

Cleaning: Before cleaning your lamp, turn off the switch or power source.

Wipe the lamp with a soft, damp fabric.

Nettoyage: Avant de nettoyer votre lampe, fermez ou coupez la source d'énergie. Essuyez la lampe avec un linge doux et humide.

Please read carefully the following instructions. It is important to make sure that the lamp is unplugged and turned off, before starting assembly or replacing a bulb.

Instructions

1. Install the bulb carefully in clockwise direction.
2. Insert the plug into a conveniently located electrical socket. The lamp is now ready for use.

Caution

1. Before changing the bulb, turn off/unplug and allow to cool.
Do not touch the bulb when the lamp is switched on.
2. If the supply cord is damaged, it must be replaced by the manufacturer or a similarly qualified person in order to avoid any danger.

Gooseneck desk lamp

Replacement bulb A19, 60W maximum (sold separately)

Veillez lire attentivement les instructions suivantes. Il est important de s'assurer que la lampe est débranchée et éteinte avant d'entamer l'assemblage ou de remplacer une ampoule.

Instructions

1. Installez l'ampoule délicatement en vissant dans le sens horaire.
2. Insérez la fiche dans une prise électrique adéquate. La lampe est maintenant prête à être utilisée.

Attention

1. Éteignez, débranchez la lampe et laissez refroidir l'ampoule avant de la changer.
Ne jamais toucher l'ampoule lorsque la lampe est allumée.
2. Si le cordon électrique est défectueux, il est préférable de le faire remplacer par le fabricant ou une personne qualifiée de façon à éviter tous dangers.

Lampe de bureau à bras articulé

Ampoule de remplacement A19, 60W maximum (vendue séparément)

For item / Pour item 1-69021 & 1-69022

